



PRESTO SMART e355

Quick Reference Guide.

October 2022



Get in touch

Merchant Helpdesk



westpac.com.au/merchantsupport



1800 029 749

(available 24 hours a day, 7 days a week)

Contents


Getting started	4
Power terminal up.	4
Getting your terminal started.	4
Activating your terminal	4
Connectivity – network & pairing	5
Connecting your Presto Smart e355 to your Point of Sale (POS) system.	5
Processing transactions – integrated mode	5
Processing a purchase.	5
Processing a refund.	6
Receipts.	6
Processing a settlement – integrated mode	7
Manual settlement.	7
Charging your terminal	7
Using a USB Cable (provided).	7
Using a wall charger.	8
Connectivity	8
Un-pairing your terminal from the POS.	8
Troubleshooting	9

Getting started

Power terminal up.

To power up the terminal, press and hold the  key for 5 seconds.

Getting your terminal started.

1. Press the  key on the terminal to get started.
2. For Wi-Fi press 1 on the terminal keypad.
3. Please select your Wi-Fi network or search for your network name.
If you cannot find your Wi-Fi network, make sure you refresh and try again.
4. Enter your Wi-Fi password using the keypad.

Activating your terminal

Your Presto Terminal will need to be activated prior to use.

If a technician has attended your premises, they will ensure your terminal is activated and ready to pair with your POS.

If you have received your terminal via satchel, for security reasons you will need to activate it first by simply calling our Merchant Helpdesk on 1800 029 749.

When you call, you will need your terminal's serial number, Merchant ID and Terminal ID provided to you.

Do not continue until instructed to do so by the banker on the phone.

Connectivity – network & pairing


Connecting your Presto Smart e355 to your Point of Sale (POS) system.


1. The technician will connect your new terminal to your local network (the same network your POS is on) via Wi-Fi. Alternatively, you can connect your new terminal to your local network by following the steps in the 'Presto Smart e355 User Guide', available on westpac.com.au/prestosupport
2. Follow the steps outlined in your POS Pairing Guide and configure your POS to pair with your Presto Smart e355 terminal.

You can find a step-by-step guide to pairing at westpac.com.au/prestosupport or by contacting your POS Provider.
3. Once paired successfully, your terminal will display 'Connected.'



Processing transactions – integrated mode

Processing a purchase.

1. Initiate a 'Purchase' transaction via the POS.
2. The terminal will prompt you to Tap, Insert or Swipe the customer's card.
3. If a contactless card is presented, position the card above the terminal screen for processing.
4. The terminal will advise if the transaction has been approved or declined.
5. Alternatively, for Insert or Swipe card processing, select the account type on the terminal.
6. The terminal will prompt the customer to enter their PIN (if required) and then press the  key.
7. The terminal will advise if the purchase has been approved or declined.



Processing a refund.

1. Initiate a 'Refund' transaction via the POS.
2. Next you'll be prompted to enter your merchant password on the terminal. Type in your password and press the  key.
3. If a contactless card is presented, position the card above the terminal screen. The terminal will advise if the transaction has been approved or declined.
4. Alternatively, for Insert or Swipe card processing, select the account type on the terminal.
5. The terminal will prompt the customer to enter their PIN (if required) and then press the  key.
6. The terminal will advise if the refund has been approved or declined.

Receipts.

Note: In Integrated mode, all receipt information is sent to your POS for printing.

Processing a settlement – integrated mode

Manual settlement.

You can perform a manual settlement any time throughout the day. This function allows you to manually settle the current trading day.



Steps.

1. Initiate a 'Settlement' transaction via the POS.
2. The terminal will connect to the bank and begin settlement.



Important: You can only perform a settlement once a day, before 9:30 pm (Sydney time). A settlement done after 11:00 pm will be processed as a settlement for the next day.


Charging your terminal

Using a USB Cable (provided).

1. Ensure your terminal is connected to a USB power source and placed on a flat surface to charge. Once charging, a battery symbol will display and your terminal will turn on automatically.
2. Turning your terminal on and off.
 - i. To turn the terminal on, press the  key for 10 seconds.
 - ii. To turn the terminal off, press the  key for 10 seconds.




Using a wall charger.

1. Ensure your terminal is connected to a wall socket and placed on a flat surface to charge. Once charging, a battery symbol will display and your terminal will turn on automatically.
2. Turning your terminal on and off.
 - i. To turn the terminal on, press the  key for 10 seconds.
 - ii. To turn the terminal off, press the  key for 10 seconds.



Connectivity




Un-pairing your terminal from the POS.

1. Press the  key and the  key at the same time.
2. The terminal will now display the Unpair terminal menu. Select “1. Unpair terminal” to continue.
3. The terminal will now display a confirmation prompt for unpairing. Select the  key and you’re done.

Note: Your terminal is now in an unconfigured state and unable to process Integrated transactions. The terminal must be paired again with the POS in order to take payments in an Integrated manner. Refer to your POS user guide for further details.


Troubleshooting

e355 terminal doesn't connect with POS app.


1. Ensure Wi-Fi is enabled on the terminal.
2. Check the terminal for the  symbol, right next to the battery icon. If there is no  symbol, attempt to connect to Wi-Fi by referring to the '[Presto Smart e355 User Guide](#)', available on westpac.com.au/prestosupport
3. If the Wi-Fi symbol on the terminal is  (red), re-attempt to connect to the Wi-Fi network by referring to the '[Presto Smart e355 User Guide](#)', available on westpac.com.au/prestosupport

Note: Remember, one POS can connect to only one terminal. If your POS is already connected to another terminal, then unpair that terminal first.

e355 terminal does not start.

1. Ensure the battery charge state is not critically low.
2. Connect the terminal to a power source for at least 15 minutes.
3. Ensure that you press the  key for approximately 5 seconds until the terminal lights up.

**e355 terminal
not reading
cards.**

1. Re-insert/swipe the card when prompted by the terminal.
2. If there is still no response from the terminal, power off the terminal by pressing the  key for 10 seconds.
3. Power on the terminal and re-connect it to your compatible POS app.
4. Attempt the transaction again.
5. Call the Westpac Merchant Helpdesk if the problem persists.

